

## **LOCAL NOTICE TO MARINERS**

District: 14 Week: 49/24

ISSUED BY:
Commander (dpw)
Fourteenth Coast Guard District
300 Ala Moana Boulevard, Room 9-220
Honolulu, HI 96850-4982
Telephone: (808) 535-3409
Email: D14-DG-PJ-dpw@uscg.mil

Email: D14-DG-PJ-dpw@uscg.mil Website: https://www.navcen.uscg.gov/

## Note:

Unless otherwise indicated, missing and destroyed structures are presumed to be in the immediate vicinity, possibly beneath the surface. Any life threatening or hazardous conditions including off station, missing, or inoperative aids to navigation should be reported immediately to U.S. Coast Guard Sector Honolulu at (808) 842-2600 and U.S. Coast Guard Sector Forces Micronesia/Sector Guam at (671) 355-4822. Mariners should proceed with caution.

## References:

Light List, Volume VI, Pacific Coast and Pacific Islands, 2024 Edition (COMDTPUB P16502.6).

U.S. Coast Pilot 10, Pacific Coast: Oregon, Washington, Hawaii, Pacific Islands 2023 (4th Edition). Coast Pilots, along with corrections, are ready for free download and weekly updates at www.nauticalcharts.noaa.gov/publications/coast-pilot/index.html.

Only Print-on-Demand (POD) bound copies are available for purchase; visit nauticalcharts.noaa.gov/publications/print-agents.html#coast-pilot.

Navigation information having been of immediate concern to the mariner, and promulgated by the following broadcasts, have been incorporated in this notice when still significant:

COMCOGARD SECTOR HONOLULU HI BNMs: 0140-24 to 145-24

COMCOGARD SECTOR FORCES MICRONESIA/SECTOR GUAM BNMs: 0365-24 to 0389-24

## **Abbreviations**

ADRIFT - Buoy Adrift	ICW - Intracoastal Waterway	R - Red
AICW - Atlantic Intracoastal Waterway	IMCH - Improper Characteristic	RACON - Radar Transponder Beacon
AI - Alternating	INL - Inlet	Ra ref - Radar reflector
B - Buoy	INOP - Not Operating	RBN - Radio Beacon
BKW - Breakwater	INT - Intensity	REBUILT - Aid Rebuilt
bl - Blast	ISL - Islet	RECOVERED - Aid Recovered
BNM - Broadcast Notice to	lso - Isophase kHz - Kilohertz	RED - Red Buoy
Mariner	LAT - Latitude	REFL - Reflective
bu - Blue	LB - Lighted Buoy	RRL - Range Rear Light
C - Canadian	LBB - Lighted Bell Buoy	RELIGHTED - Aid Relit
CHAN - Channel	LHB - Lighted Horn Buoy	RELOC - Relocated
CGD - Coast Guard District  C/O - Cut Off	LGB - Lighted Gong Buoy	RESET ON STATION - Aid Reset on Station
CONT - Contour	LONG - Longitude	RFL - Range Front Light
CRK - Creek	LNM - Local Notice to Mariners	RIV - River
CONST - Construction	LT - Light	RRASS - Remote Radio
DAYMK/Daymk - Daymark	LT CONT - Light Continuous	Activated
DBN/Dbn - Daybeacon	LTR - Letter	Sound Signal
DBD/DAYBD - Dayboard	LWB - Lighted Whistle Buoy	s - seconds
DEFAC - Defaced	LWP - Left Watching Properly	SEC - Section
DEST - Destroyed	MHz - Megahertz	SHL - Shoaling
DISCON - Discontinued	MISS/MSNG - Missing	si - silent
DMGD/DAMGD - Damaged	Mo - Morse Code	SIG - Signal
ec - eclipse	MRASS - Marine Radio Activated	SND - Sound
EST - Established Aid	Sound Signal	SPM - Single Point Mooring Buoy
ev - every	MSLD - Misleading	SS - Sound Signal
EVAL - Evaluation	N/C - Not Charted	STA - Station
EXT - Extinguished	NGA - National Geospatial Intelligence Agency	STRUCT - Structure
F - Fixed	NO/NUM - Number	St M - Statute Mile
fl - flash	NOS - National Ocean Service	TEMP - Temporary Aid Change
FI - Flashing	NW - Notice Writer	TMK - Topmark
G - Green	OBSCU - Obscured	TRLB - Temporarily Replaced by Lighted Buoy
GIWW - Gulf Intracoastal Waterway	OBST - Obstruction	TRLT - Temporarily Replaced by Light
	OBSTRR - Obstruction	

HAZ - Hazard to Navigation

HBR - Harbor I - Interrupted PRIV - Private Aid

Q - Quick

TRUB - Temporarily Replaced by Unlighted Buoy

USACE - Army Corps of Engineers