U.S. Department of Homeland Security

**United States Coast Guard** 



## LOCAL NOTICE TO MARINERS

District: 5

Week: 49/24

COASTAL WATERS FROM SHREWSBURY RIVER, NEW JERSEY TO LITTLE RIVER, SOUTH CAROLINA

The Local Notice to Mariners contains all information relevant to the waterways within the Fifth Coast Guard District and is updated each Tuesday on

the U.S. Coast Guard Navigation Center website at https://www.navcen.uscg.gov/.

If you have questions about the Fifth Coast Guard District Local Notice to Mariners (LNM), please contact:

COMMANDER FIFTH COAST GUARD DISTRICT (dpw) 431 Crawford Street Portsmouth, Virginia 23704 or for correspondence and article requests: gregory.c.goetz2@uscg.mil, (571) 613-1472 and CGD5Waterways@uscg.mil

All bearings are in degrees TRUE - All times are in Local Time unless otherwise noted.

AIDS TO NAVIGATION DISCREPANCY REPORTING

To report any Aids to Navigation discrepancies (missing, damaged, extinguished lights, off station), shoaling or hazards to navigation, discrepancies to bridge lighting, please contact the following 24 hour numbers:

1. For PA, NJ, DE waters, coastal and tributaries contact COGARD SECTOR DELAWARE BAY at (215) 271-4940.

2. For MD, DE in the Upper Chesapeake Bay and tributaries contact COGARD SECTOR MARYLAND - NATIONAL CAPITAL REGION at (410) 576-2525.

3. For VA in Lower Chesapeake Bay below Smith Point Light and tributaries and VA, MD Eastern Shore Bay and coastal contact COGARD SECTOR VIRGINIA at (757) 483-8567.

4. For NC waters, coastal and tributaries contact COGARD SECTOR NORTH CAROLINA at (910) 343-3882.

REFERENCES

Light List: ATLANTIC COAST, VOLUME II, COMDTPUB P16502.2, 2024 Edition. U.S. Coast Pilot 3, Atlantic Coast: Sandy Hook, NJ to Cape Henry, VA, 2024 (57th) Edition. U.S. Coast Pilot 4, Atlantic Coast: Cape Henry, VA to Key West, FL, 2024 (56th) Edition.

> NAVIGATION INTERNET SITES 2024 Light List/ Weekly Updates. https://www.navcen.uscg.gov/weekly-light-lists

Bridges Public Notice Website. https://www.navcen.uscg.gov/bridge-notices

NOAA Chart Corrections and Chart Viewer http://www.nauticalcharts.noaa.gov

Coast Pilots, along with corrections are available at https://nauticalcharts.noaa.gov/publications/coast-pilot/index.html

D5 LNM Archived Back Issues https://www.navcen.uscg.gov/archives

Chesapeake Bay NOAA Weather Buoys www.buoybay.noaa.gov

Tides, Currents, PORTS http://www.tidesandcurrents.noaa.gov

> Weather http://www.weather.gov

## Abbreviations

ADRIFT - Buoy Adrift ICW - Intracoastal Waterway AICW - Atlantic Intracoastal Waterway AI - Alternating INL - Inlet B - Buoy **BKW - Breakwater** bl - Blast ISL - Islet BNM - Broadcast Notice to Mariner bu - Blue C - Canadian CHAN - Channel CGD - Coast Guard District C/O - Cut Off CONT - Contour **CRK - Creek CONST** - Construction DAYMK/Daymk - Daymark LT - Light DBN/Dbn - Daybeacon DBD/DAYBD - Dayboard LTR - Letter **DEFAC** - Defaced **DEST** - Destroyed **DISCON** - Discontinued DMGD/DAMGD - Damaged ec - eclipse EST - Established Aid ev - every **EVAL** - Evaluation EXT - Extinguished F - Fixed Agency fl - flash FI - Flashing G - Green GIWW - Gulf Intracoastal Waterway HAZ - Hazard to Navigation HBR - Harbor I - Interrupted PRIV - Private Aid

IMCH - Improper Characteristic **INOP** - Not Operating **INT - Intensity** Iso - Isophase kHz - Kilohertz LAT - Latitude LB - Lighted Buoy LBB - Lighted Bell Buoy LHB - Lighted Horn Buoy LGB - Lighted Gong Buoy LONG - Longitude LNM - Local Notice to Mariners LT CONT - Light Continuous LWB - Lighted Whistle Buoy LWP - Left Watching Properly MHz - Megahertz MISS/MSNG - Missing Mo - Morse Code MRASS - Marine Radio Activated Sound Signal MSLD - Misleading N/C - Not Charted NGA - National Geospatial Intelligence NO/NUM - Number NOS - National Ocean Service NW - Notice Writer **OBSCU** - Obscured **OBST** - Obstruction **OBSTRR** - Obstruction

Q - Quick

R - Red RACON - Radar Transponder Beacon Ra ref - Radar reflector **RBN** - Radio Beacon **REBUILT - Aid Rebuilt RECOVERED** - Aid Recovered RED - Red Buoy **REFL** - Reflective RRL - Range Rear Light **RELIGHTED - Aid Relit RELOC** - Relocated **RESET ON STATION - Aid Reset on** Station RFL - Range Front Light **RIV** - River **RRASS - Remote Radio Activated** Sound Signal s - seconds SEC - Section SHL - Shoaling si - silent SIG - Signal SND - Sound SPM - Single Point Mooring Buoy SS - Sound Signal STA - Station STRUCT - Structure St M - Statute Mile **TEMP** - Temporary Aid Change TMK - Topmark TRLB - Temporarily Replaced by Lighted Buoy TRLT - Temporarily Replaced by Light TRUB - Temporarily Replaced by Unlighted Buoy USACE - Army Corps of Engineers